



TABLA DE AJUSTE PARA L¹ SERIE G7 HUSTLER

Frecuencia (MHz.)
G7-136 136-144 MHz.

	"X"	"Y"	"Z"
136	131.445	50.5	128.27
137	130.81	50.25	127.635
138	130.175	50	127.005
139	129.54	49.75	126.365
140	128.905	49.5	125.73
141	128.27	49.25	125.095
142	127.635	49	124.46
143	127.005	48.75	123.825
144	126.365	48.5	123.19
145	125.73	48.25	122.555
146	125.095	48	121.92
147	124.46	47.75	121.285
148	123.825	47.5	120.65
149	123.19	47.25	120.015
150	122.555	47	119.38
151	121.92	46.75	118.745
152	121.285	46.5	118.11
153	120.65	46.25	117.475
154	120.015	46	116.84

G7-144 143-149 MHz.

	"X"	"Y"	"Z"
143	122.555	46.75	118.745
144	121.92	46.5	118.11
145	121.285	46.25	117.475
146	120.65	46	116.84
147	120.015	45.75	116.205
148	119.38	45.5	115.57
149	118.745	45.25	114.935
150	118.11	45	114.3
151	117.475	44.75	113.665
152	116.84	44.5	113.03
153	116.205	44.25	112.395
154	115.57	44	111.76
155	114.935	43.75	111.125

G7-150-1 148-154 MHz.

	"X"	"Y"	"Z"
148	119.38	45.625	115.8875
149	118.745	45.375	115.2525
150	118.11	45.125	114.6175
151	117.475	44.875	113.9825
152	116.84	44.625	113.3475
153	116.205	44.375	112.7125
154	115.57	44.125	112.0775
155	114.935	43.875	111.4425
156	114.3	43.625	110.8075
157	113.665	43.375	110.1725
158	113.03	43.125	109.5375
159	112.395	42.875	108.9025
160	111.76	42.625	108.2675

Nota: Todas las medidas están en centímetros

G7-150-2 154-161 MHz.

	"X"	"Y"	"Z"
154	154	154	154
155	155	155	155
156	156	156	156
157	157	157	157
158	158	158	158
159	159	159	159
160	160	160	160
161	161	161	161

G7-150-3 161-167 MHz.

	"X"	"Y"	"Z"
161	161	161	161
162	162	162	162
163	163	163	163
164	164	164	164
165	165	165	165
166	166	166	166
167	167	167	167

G7-150-4 167-174 MHz.

	"X"	"Y"	"Z"
167	167	167	167
168	168	168	168
169	169	169	169
170	170	170	170
171	171	171	171
172	172	172	172
173	173	173	173
174	174	174	174

Nota: Todas las medidas están en centímetros

